


Number	Part Number	Name	Quantity
1	31781	NUT 7/16-20	1,000
2	31787	BOLT 1/2-13X1.0	1,000
3	31791	NUT 10-24 LOCK	1,000
4	31792	SCREW 1/4-20X0.75	1,000
5	31768	BOLT 3/8-16X1	1,000
6	31767	BOLT 5/16-18X4	1,000
7	31764	BOLT 7/16-20X1.5	1,000
8	33002	BOLT	1,000
9	33006	NUT	1,000
10	33010	NUT 1/2-13	1,000
11	33019	STOP NUT10-120	1,000
12	33022	NUT	1,000
13	31823	WASHER 1/2 LOCK	1,000
14	31825	WASHER 7/16"	1,000
15	33045	SCREW	1,000
16	31913	SCREW	1,000
17	31899	SEATCOMPLETE	1,000
31	31896	ROPS ATM72	1,000
32	33198	BRACKET	1,000
33	33079	HANDLE CLAMP	1,000
34	33080	FENDER SKIRT	1,000
35	33094	SWITCH GUARD	1,000
36	33095	BACK GUARD	1,000
37	33096	BRACKET	1,000
38	31898	HANDLE WELDMENT	1,000
39	31897	BRACKET	1,000
40	33108	FRAME	1,000
41	33259	SEAT SWITCH	1,000


A180/1



03/2006

Number	Part Number	Name	Quantity
1	33145	SCREW M12X1,75X30	1,000
2	31793	BOLT 1/2-13X2.0	1,000
3	31794	NUT	1,000
4	31977	WHEEL SCREW	1,000
5	31842	BOLT 3/8-16X1.5	1,000
6	31851	BOLT	1,000
7	31845	NUT SLOTTED 1.0-20	1,000
8	33022	NUT	1,000
9	33152	WASHER 5/16	1,000
10	33045	SCREW	1,000
11	31982	PIN	1,000
12	31843	KEY	1,000
13	31989	BRAKE HANDLE ASS.	1,000
14	31990	AXLE	1,000
15	33049	COTTER PIN 3/32	1,000
16	33051	BUSHING	1,000
17	31846	RIM	1,000
18	31969	CENTRAL TYRE	1,000
19	33197	SAFETY SWITCH STOP	1,000
20	31405	SWITCH	1,000
21	33115	E-CLIP	1,000
22	31815	BRAKE DRUM	1,000
23	31992	CABLE BRAKE	1,000
24	31994	REAR BRAKE	1,000
25	31991	CLEVIS YOKE	1,000
27	33116	BRAKE SHOE	1,000
28	33117	BRAKE CYLINDER	1,000
29	33118	SPRING	1,000
30	33119	SPRING	1,000
31	33120	SPRING	1,000
32	31976	BRAKE SHOE	1,000


A180/2



03/2006

Number	Part Number	Name	Quantity
1	31892	ROLL PIN	1,000
2	31889	CLIP E-CLIP E-025	1,000
3	33001	BOLT	1,000
4	33015	NUT 1/4-28	1,000
5	33020	NUT	1,000
6	31891	NUT 1/4-28 LOCK	1,000
7	33101	WIRE SEAL	1,000
8	33102	CLIP	1,000
9	33040	SCREW 10X24X1	1,000
10	31890	BEARING	1,000
11	31888	THROTTLE CABLE	1,000
12	31893	FOOT PEDAL ASSY	1,000
13	33069	BRACKET	1,000
14	31895	TRACTION LEVER	1,000
15	31894	TRACTION PAD	1,000
16	33121	LINKAGE	1,000


A180/3



12/2007

Number	Part Number	Name	Quantity
1	31790	WASHER	1,000
2	31793	BOLT 1/2-13X2.0	1,000
3	31821	BOLT 3/8-16X1,25	1,000
4	31977	WHEEL SCREW	1,000
5	31770	BOLT 3/8-16X2.50	1,000
6	33008	NUT SLOTTED .75-10	1,000
7	33016	NUT 3/8-16	1,000
8	31845	NUT SLOTTED 1.0-20	1,000
9	31738	PIN	1,000
10	31835	BEARING	1,000
11	31834	SEAL CR29865	1,000
12	31841	GREASE ZERK 1/4-28	1,000
13	31911	COTTER PIN 1/8X1	1,000
14	31836	BEARING CUP 2.5625	1,000
15	31961	KEY	1,000
16	31982	PIN	1,000
17	31843	KEY	1,000
18	33051	BUSHING	1,000
21	31839	SEAL	1,000
22	31837	BEARING CUP	1,000
23	31838	BEARING LOWER	1,000
24	31840	STEERING TOWER	1,000
25	31832	STEERING ARM ASSY	1,000
26	33107	ARM	1,000
27	31844	FRONT WHEEL HUB	1,000


A180/4



03/2006

Number	Part Number	Name	Quantity
1	31780	CLAMP HOSE	1,000
2	31779	BOLT 3/8-16X2.75	1,000
3	33003	BOLT 3/8-16-X2.25	1,000
4	31826	WASHER 3/8 LOCK	1,000
5	31887	ADAPTER 4BH-4MP90	1,000
6	31885	FUEL SHUT OFF VALVE	1,000
7	31886	REDUCER	1,000
8	31883	FUEL TANK	1,000
9	33050	FUEL HOSE	1,000
10	31884	FUEL CAP	1,000
11	33084	FUEL TANK RISER	1,000
12	33106	SPACER	1,000
13	31975	FUEL GAUGE	1,000


A180/5



03/2006

Number	Part Number	Name	Quantity
1	31912	SCREW	1,000
2	31784	WASHER	1,000
3	31786	BOLT 3/4-10X5.0	1,000
4	31796	WASHER 1/4" SAE	1,000
5	31799	BOLT 1/2-13X2	1,000
6	31821	BOLT 3/8-16X1,25	1,000
7	31772	BOLT 1/2-13X1.5	1,000
8	31851	BOLT	1,000
9	33007	NUT 5/16-18	1,000
10	33010	NUT 1/2-13	1,000
11	33018	NUT	1,000
12	31877	WASHER	1,000
13	31823	WASHER 1/2 LOCK	1,000
14	31979	PIN	1,000
15	31911	COTTER PIN 1/8X1	1,000
16	31913	SCREW	1,000
17	33103	PLASTIC BUMPER	1,000
18	31910	ROD	1,000
19	31901	DECK AJUSTER	1,000
20	31904	PLASTIC DECK COVER	1,000
21	31900	BUSHING	1,000
22	31907	RIGHT SHIELD	1,000
23	31908	CORNER SHIELD LEFT	1,000
24	31909	DECK LIFT FLAP	1,000
25	33083	FLAP STRAP	1,000
26	31905	REAR DECK FLAP	1,000
27	31906	FRONT DECK FLAP	1,000
28	31903	REAR DECK FLAP	1,000
29	31902	TAPPED HOLES ASSY.9	1,000
30	33262	FEELING SCREW	1,000
31	33263	SPACER	1,000


A180/6



12/2007

Number	Part Number	Name	Quantity
1	31866	BUSHING 1.5X1.25	1,000
2	31865	WASHER	1,000
3	31784	WASHER	1,000
4	31864	BOLT	1,000
5	31787	BOLT 1/2-13X1.0	1,000
6	31851	BOLT	1,000
7	31877	WASHER	1,000
8	31823	WASHER 1/2 LOCK	1,000
9	31849	THUMB SCREW	1,000
10	31879	PIN	1,000
11	33039	GREASE NIPPEL	1,000
12	31841	GREASE ZERK 1/4-28	1,000
13	33041	PIN 3-16X2	1,000
14	31882	HUB ASSEMBLY	1,000
15	33014	NUT 1/2-20 LUG	1,000
16	31880	PIN	1,000
17	31881	DUST CAP 1428600	1,000
18	31869	PIN	1,000
19	31868	BUSHING	1,000
20	31854	BUSHING	1,000
21	31970	STAB.WHEEL	1,000
22	31860	BUSHING	1,000
23	31871	BUSHING	1,000
24	31872	BUSHING	1,000
25	31873	BUSHING	1,000
26	31863	BUSHING 2024-24	1,000
27	31850	KNOB	1,000
28	31874	PIN	1,000
29	31862	EQUALIZER ARM ASSY	1,000
30	31875	PIN	1,000
31	31861	PIN	1,000
32	31878	BUSHING	1,000
33	31867	VERTICAL SHAFT	1,000
34	31859	ARM	1,000
35	31858	ARM	1,000
36	31965	LEFT STAB. ARM	1,000
37	31966	RIGHT STAB.ARM	1,000
38	31855	SLIDE ASSY.	1,000
39	31847	RIGHT HANDLE	1,000
40	31848	LEFT HANDLE	1,000
41	31870	CYLINDER 2.5X6.56	1,000


A180/7



03/2006

Number	Part Number	Name	Quantity
1	31864	BOLT	1,000
2	33264	SCREW	1,000
3	31776	BOLT 1/2-13X1.75	1,000
4	31768	BOLT 3/8-16X1	1,000
5	31963	BLADE SCREW	1,000
6	33012	NUT	1,000
7	33018	NUT	1,000
8	33022	NUT	1,000
9	33023	WASHER	1,000
10	33153	WASHER 7/16	1,000
11	33028	WASHER	1,000
12	33029	PIN	1,000
13	33038	ROLL PIN 1/4X1.5	1,000
14	MC180	SET 4 BLADES - A180	1,000
15	33204	RIGHT ARM	1,000
16	31953	BOLT SET	1,000
17	31783	BOLT	1,000
18	33021	NUT	1,000
19	33205	LEFT ARM	1,000
20	33048	BLADE MOUNT BUSHING	1,000
21	31841	GREASE ZERK 1/4-28	1,000
22	31961	KEY	1,000
23	33046	PIN 14-13	1,000
24	31964	WHEEL	1,000
25	33052	BUSHING	1,000
26	33185	PROTECTIVE COATING	1,000
27	33100	BUSHING	1,000
28	31954	ENGINE COUPLING	1,000
29	31962	BLADE WASHER	1,000
30	31950	BLADE BODY	1,000
31	31955	BLADE COUPLING	1,000
32	33193	RIGHT LEVER	1,000
33	33194	LEFT LEVER	1,000
34	33195	CUT.DECK RIGHT	1,000
35	33196	CUT.DECK LEFT	1,000
36	33097	DUST CAP	1,000
37	33202	HOLDER	1,000
38	33203	SCREW.AXLE	1,000


A180/8



03/2006

Number	Part Number	Name	Quantity
1	33152	WASHER 5/16	1,000
2	31788	POP RIVET	1,000
3	31794	NUT	1,000
4	31775	BOLT	1,000
5	31774	BOLT 5/16-18X1.0	1,000
6	31766	BOLT	1,000
7	33006	NUT	1,000
8	33007	NUT 5/16-18	1,000
9	33030	BOLT 5/16-18	1,000
10	31809	HOOD LIFT ARM REAR	1,000
11	31807	LIFT ARM	1,000
12	31806	LIFT ARM	1,000
13	31805	SAFETY CATCH	1,000
14	31808	HOOD LIFT BRACKET	1,000
15	31802	HOOD ATTILA 180	1,000
16	31810	TOP SCREEN	1,000
17	31800	GRILL FRONT	1,000
18	31801	GRILL SIDE RIGHT	1,000
19	31803	GRILL SIDE LEFT	1,000
20	31804	SPRING	1,000


A180/9



03/2006

Number	Part Number	Name	Quantity
1	31983	CLIPS NUT	1,000
2	31788	POP RIVET	1,000
3	31981	SCREW 1/4 20X1	1,000
4	31771	BOLT 1/4-20X1.25	1,000
5	33005	BOLT 1/4-20X.75	1,000
6	33019	STOP NUT10-120	1,000
7	33020	NUT	1,000
8	33025	WASHER 1/4 FLAT	1,000
9	31980	NYLON WASHER 1/4"	1,000
10	31814	LATCH	1,000
11	33040	SCREW 10X24X1	1,000
12	31813	COWLING DASH	1,000
13	31811	RIGHT COWLING	1,000
14	31812	LEFT COWLING	1,000
15	33073	BRACKET	1,000
16	33074	BRACKET	1,000
17	33078	INSTRUMENT BOARD	1,000
18	31815	BRAKE DRUM	1,000
19	33092	HOOD LATCH LEFT	1,000
20	33093	HOOD LATCH RGHT	1,000
21	33251	LEFT COVER BRACKET	1,000


A180/10



12/2007

Number	Part Number	Name	Quantity
1	33150	SCREW	1,000
2	33151	NUT 5/16-18	1,000
3	31986	ADAPTER 10MJ-12MB90	1,000
4	33157	ADAPTER 8MJ/8MJ	1,000
5	33032	ADAPTER 4MJ-4MJ	1,000
6	33034	ADAPTER 4MJ/4MB90	1,000
7	33162	ADAPTER 10MJ/10MB	1,000
8	33165	ADAPTER 10MB/10MB	1,000
9	31780	CLAMP HOSE	1,000
10	33186	HYD.OIL COOLER	1,000
11	31702	HOSE/CASE DRAIN	1,000
12	31925	VALVE DECK CONTROL	1,000
13	31703	HOSE DECK/COLLER	1,000
14	31704	HOSE VAL/MANIFOLD	1,000
15	31705	HOSE VAL/FR.MANIFOL	1,000
16	31706	HOSE VAL/MANIFOLD	1,000
17	31723	HOSE ENG/ADAPTER	1,000
18	31724	HOSE ENG/ADAPTER	1,000
19	31725	HOSE ENG/ENG	1,000
20	31729	RETURN HOSE ASSY	1,000
21	31730	HOSE BLADE ENGINE	1,000
22	31732	HOSE SUCTION	1,000
23	33213	HOSE	1,000
24	31996	BLADE ENGINE A180	1,000
25	31997	RIGHT BLADE ENGINE	1,000
26	33226	INLINE FILTER	1,000
27	33129	SEAL KIT	1,000


A180/11



04/2010

Number	Part Number	Name	Quantity
1	31777	BOLT 1/4-20X2.25	1,000
2	33009	NUT 1/4-20	1,000
3	33024	WASHER 1/4 LOCK	1,000
4	33025	WASHER 1/4 FLAT	1,000
5	31933	ADAPTER 6MJ-6MB	1,000
6	31929	CYLINDER	1,000
7	31928	CYLINDER	1,000
8	31971	CUT.HGT DISTRIBUTOR	1,000
9	31711	HOSE VAL./FR.CYL.	1,000
10	31714	HOSE CYL./FILTER	1,000
11	31720	HOSE VAL./REAR CYL	1,000
12	31737	HOSE LEV.VAL/FIL.	1,000


A180/12



03/2006

Number	Part Number	Name	Quantity
1	31798	BOLT 5/16-18X2	1,000
2	33033	ADAPTER 10MJ/10MB90	1,000
3	31780	CLAMP HOSE	1,000
4	31995	MOTOR WHEEL ME29	1,000
5	33211	HOSE CLAMP ASSY	1,000
6	31726	HOSE ENG/PUMP	1,000
7	31727	HOSE WH/WH	1,000
8	31728	HOSE ENG/PUMP	1,000
9	31731	HOSE SUCTION	1,000
10	31734	HOSE PUMP DRAIN	1,000


A180/13



03/2006

Number	Part Number	Name	Quantity
1	31988	ROLL PIN 3/16X1.5	1,000
2	31778	BOLT	1,000
3	31777	BOLT 1/4-20X2.25	1,000
4	31772	BOLT 1/2-13X1.5	1,000
5	33004	BOLT	1,000
6	33019	STOP NUT10-120	1,000
7	31877	WASHER	1,000
8	31823	WASHER 1/2 LOCK	1,000
9	33024	WASHER 1/4 LOCK	1,000
10	31826	WASHER 3/8 LOCK	1,000
11	31986	ADAPTER 10MJ-12MB90	1,000
12	31949	ADAPTER 8MB-8MJ45	1,000
13	31984	ADAPTER 6MJ/8MB90	1,000
14	31987	ADAPTER 12MJ-16MB90	1,000
15	31985	ADAPTER 12MJ-8MB	1,000
16	31948	ADAPTER 8MJ-8MB	1,000
17	33039	GREASE NIPPEL	1,000
18	31947	BUSHING	1,000
19	33064	CUTTING DECK	1,000
20	31943	COUPLING	1,000
21	33200	SWITCH BRACKET	1,000
22	33201	STRUT	1,000
23	33206	FOOT PEDAL BRACKET	1,000
24	33207	LEVER	1,000
25	33210	SAFETY SWITCH STOP	1,000
26	33143	O-RING	1,000
27	33130	PUMP DECK DRIVE	1,000
28	31944	PROPULSION PUMP	1,000
29	33265	33265	1,000


A180/14



03/2006

Number	Part Number	Name	Quantity
1	31824	BOLT	1,000
2	31768	BOLT 3/8-16X1	1,000
3	31920	BOLT 1/4-20X50	1,000
4	33017	NUT 5/16-24	1,000
5	33022	NUT	1,000
6	31825	WASHER 7/16"	1,000
7	31918	ADAPT.6MJ/6MJ/6MB	1,000
8	33032	ADAPTER 4MJ-4MJ	1,000
9	31919	ADAPTER 6MJ-6MB90	1,000
10	33034	ADAPTER 4MJ/4MB90	1,000
11	31968	FILTER CARTRIDGE	1,000
12	31921	CYLINDER	1,000
13	31915	STEERING COLUMN	1,000
14	31916	PUMP STEERING	1,000
15	31914	STEERING WHEEL	1,000
16	33077	OIL FILTER BRACKET	1,000
17	33104	STEERING PUMP MOUNT	1,000
18	31709	HOSE STEER./ADAPTER	1,000
19	31710	HOSE CYL./ADAPTER	1,000
20	31736	HOSE FILTER-PUMP	1,000
21	31917	FILTER HEAD	1,000
22	33256	NUT	1,000


A180/15




03/2006

Number	Part Number	Name	Quantity
1	31713	HOSE STEER./VALVE	1,000
2	31733	HOSE PUMP/PUMP	1,000
3	31708	HOSE STEER./ADAPTER	1,000
4	31707	HOSE STEER./ADAPTER	1,000
5	31735	HOSE FIL/STEER.	1,000


A180/16



STEERING SYSTEM




VIEW FROM BOTTOM




03/2006

Number	Part Number	Name	Quantity
1	33148	SCREW 5/16-18X2,5	1,000
2	33007	NUT 5/16-18	1,000
3	31918	ADAPT.6MJ/6MJ/6MB	1,000
4	33158	ADAPTER 4MJ/4MP90	1,000
5	33159	ADAPT.6MJ/6FJX/6MJ	1,000
6	33160	ADAPTER 4MJ/8MB90	1,000
7	33161	ADAPTER 4MJ/4MB	1,000
8	33163	ADAPTER 4FJX/4MP	1,000
9	31933	ADAPTER 6MJ-6MB	1,000
10	33169	CLAMP	1,000
11	33171	ACCUMULATOR	1,000
12	31870	CYLINDER 2.5X6.56	1,000
13	31924	VALVE	1,000
14	31715	HOSE VAL./CYL.RGHT	1,000
15	31716	HOSE C2/CYL.LEFT	1,000
16	31717	HOSE VAL/ACCU	1,000
17	31718	HOSE C2/CYL.RGHT	1,000
18	31719	HOSE VAL./CYL.LEFT	1,000
19	31721	HOSE VAL/ACCU.	1,000
20	33214	VALVE	1,000
21	33215	VALVE	1,000



Number	Part Number	Name	Quantity
1	31768	BOLT 3/8-16X1	1,000
2	31765	BOLT 3/8-16X1.25	1,000
3	33022	NUT	1,000
4	31826	WASHER 3/8 LOCK	1,000
5	31940	ADAPTER 8MP/8FPX45	1,000
6	31937	ADAPTER 12BH-12MP	1,000
7	31941	ADAPTER 6MJ-6MP	1,000
8	31936	ADPATER 12MJ-16MB	1,000
9	31939	ADAPTER 8BH/8MP	1,000
10	31942	PLUG 3/8"	1,000
11	31934	TANK	1,000
12	31978	HYD.OIL GAUGE	1,000
13	33140	HYD.OIL FILTER CPLT	1,000
14	33141	FILTER COVER	1,000
15	33142	AIR FILTER PROTECT.	1,000
16	33143	O-RING	1,000
17	31938	OIL TEMP SWITCH	1,000
18	33138	COLMAT.INDICATOR	1,000
19	33139	GASKET SET	1,000
20	31959	FILTER CARTRIDGE	1,000
21	31960	AIR CARTRIDGE	1,000
22	33257	OIL TEMP.SENSOR	1,000


A180/18



12/2007

Number	Part Number	Name	Quantity
1	31986	ADAPTER 10MJ-12MB90	1,000
2	33156	ADAPTER 4G/4FJX90M	1,000
4	31949	ADAPTER 8MB-8MJ45	1,000
5	31940	ADAPTER 8MP/8FPX45	1,000
6	33158	ADAPTER 4MJ/4MP90	1,000
8	31937	ADAPTER 12BH-12MP	1,000
9	33161	ADAPTER 4MJ/4MB	1,000
10	31984	ADAPTER 6MJ/8MB90	1,000
11	31941	ADAPTER 6MJ-6MP	1,000
12	31987	ADAPTER 12MJ-16MB90	1,000
13	31985	ADAPTER 12MJ-8MB	1,000
14	31936	ADAPTER 12MJ-16MB	1,000
15	31948	ADAPTER 8MJ-8MB	1,000
16	31939	ADAPTER 8BH/8MP	1,000
17	33163	ADAPTER 4FJX/4MP	1,000
18	33164	ADAPTER 4C2-6FJX45	1,000


A180/19



03/2006

Number	Part Number	Name	Quantity
1	31918	ADAPT.6MJ/6MJ/6MB	1,000
2	33157	ADAPTER 8MJ/8MJ	1,000
3	33032	ADAPTER 4MJ-4MJ	1,000
4	33159	ADAPT.6MJ/6FJX/6MJ	1,000
5	33160	ADAPTER 4MJ/8MB90	1,000
6	33162	ADAPTER 10MJ/10MB	1,000
7	31933	ADAPTER 6MJ-6MB	1,000


A180/20



03/2006

Number	Part Number	Name	Quantity
1	33124	COIL DECK VALVE	1,000
2	33125	VALVE	1,000
3	33126	PRESSURE VALVE	1,000
4	33127	SPOOL DECK VALVE	1,000
5	33258	VALVE	1,000
6	33128	SPOOL	1,000
7	33269	VALVE	1,000


A180/21




03/2006

Number	Part Number	Name	Quantity
1	31929	CYLINDER	1,000
2	31928	CYLINDER	1,000
3	31870	CYLINDER 2.5X6.56	1,000
4	31921	CYLINDER	1,000
5	33133	SEAL KIT	1,000
6	31930	SEAL KIT	1,000
7	31926	SEAL KIT	1,000
8	31922	SEAL KIT 4C0441	1,000
9	31931	RETAINING RING	1,000
10	31932	RETAINING RING	1,000
11	31927	RETAINING RING	1,000
12	31923	CYLINDER WIRE	1,000

A180/22





CYLINDER / PART NUMBER		SEAL KIT	RETAINING RING
FRONT DECK LIFT	1	5	9
REAR DECK LIFT	2	6	10
LEVELING	3	7	11
STEERING	4	8	12



03/2006

Number	Part Number	Name	Quantity
1	31795	BOLT 3/4-10X6.75	1,000
2	31771	BOLT 1/4-20X1.25	1,000
3	31851	BOLT	1,000
4	31817	BOLT	1,000
5	33000	BOLT 1/4-20X0.75	1,000
6	33007	NUT 5/16-18	1,000
7	33009	NUT 1/4-20	1,000
8	33017	NUT 5/16-24	1,000
9	33020	NUT	1,000
10	31823	WASHER 1/2 LOCK	1,000
11	33024	WASHER 1/4 LOCK	1,000
12	33025	WASHER 1/4 FLAT	1,000
13	33035	INSULATOR CAP	1,000
14	33036	BATTERY BOOT RED	1,000
15	33037	BATTERY BOOT BLACK	1,000
16	33040	SCREW 10X24X1	1,000
17	33045	SCREW	1,000
18	33173	BLINKER UNIT	1,000
19	31751	SENDER OIL PRESSURE	1,000
20	33176	RELAY	1,000
21	33075	BRACKET	1,000
22	33099	BATTERY HOLD	1,000
23	33208	BRACKET	1,000
24	33110	HEADLIGHT RIGHT	1,000
25	33111	HEADLIGHT LEFT	1,000
26	33112	STARTER COVER	1,000
27	33218	BATTERY	1,000
28	31753	HORN	1,000
29	31750	BATTERY FUSE	1,000
30	33114	FACE PLATE	1,000
31	31752	COLL.TEMP SWITCH	1,000
32	28689	LIGHT	1,000


A180/23



12/2007

Number	Part Number	Name	Quantity
1	33179	CRANK + COVER	1,000
2	33180	SPRING	1,000
3	33181	SPRING	1,000
4	33182	GROMMET	1,000
5	33188	BRACKET	1,000
6	33189	ADJ.STOP BOTTOM	1,000
7	33190	ADJ.STOP TOP	1,000
8	33191	SCREW STOP	1,000
9	33192	BRACKET	1,000
10	33005	BOLT 1/4-20X.75	1,000
11	33040	SCREW 10X24X1	1,000
12	33155	SCREW 10-24X0,75	1,000
13	33147	SCREW 10-24X0,313	1,000
14	33020	NUT	1,000
15	33168	PLUG	1,000
16	33166	CLAMP	1,000
17	33132	SWITCH MERCURY	1,000
18	33177	THIMBLE	1,000
19	30179	2 WAY FEM.CONNECTOR	1,000
20	33183	STICKER	1,000
21	33184	STICKER	1,000
22	30178	DEUTSCH MALE THIMBL	1,000
24	33267	PROTECTION STICKER	1,000
25	33268	WASHER	1,000


A180/24



03/2006

Number	Part Number	Name	Quantity
1	33219	RELAY ELECTR.WIRING	1,000
2	33220	INSTR.PANEL WIRING	1,000
3	33221	REAR ELECT.WIRING	1,000
4	33222	FRONT ELECTR.WIRING	1,000



A180/25



03/2006

Number	Part Number	Name	Quantity
1	52779	HOUR METER	1,000
2	31759	OIL PRESSURE GAUGE	1,000
3	31757	INDICATOR LIGHT	1,000
4	31760	VOLT METER	1,000
5	31758	TEMPERATURE GAUGE	1,000
6	31761	IGNITION SWITCH	1,000
7	33216	KEY	1,000
8	29273	EXT. FRAME	1,000
9	33113	SWITCH MOUNT MIDDLE	1,000
10	29624	BLINKER UNIT	1,000
11	29274	MOUNTING FRAME	1,000
12	52494	SWITCH	1,000
13	52495	SWITCH ON/OFF/ON	1,000
14	29299	SWICH ON/OFF/ON C11	1,000
15	29262	SWITCH ON/OFF/ON R	1,000
16	52497	SWITCH ON/OFF LIGHT	1,000
17	29260	SWITCH ON/OFF/ON V	1,000
19	52496	SWITCH ON/OFF/ON	1,000


A180/26



03/2006

Number	Part Number	Name	Quantity
1	31794	NUT	1,000
2	31851	BOLT	1,000
3	31766	BOLT	1,000
4	33149	SCREW 1/4-20X1	1,000
5	33007	NUT 5/16-18	1,000
6	33009	NUT 1/4-20	1,000
7	33020	NUT	1,000
8	33024	WASHER 1/4 LOCK	1,000
9	33155	SCREW 10-24X0,75	1,000
10	33045	SCREW	1,000
11	33197	SAFETY SWITCH STOP	1,000
12	33085	BRACKET	1,000
13	33086	BRACKET	1,000
14	33199	SWITCH BRACKET	1,000
15	33209	BUMPER	1,000
16	33217	SECURITY SWITCH	1,000
17	31405	SWITCH	1,000
18	33224	SAFETY SWITCH	1,000
19	33223	HARNES NEUTR.SWITC	1,000


A180/27



03/2006

Number	Part Number	Name	Quantity
1	31782	WASHER	1,000
2	33146	STOPMUTTER M8X1,25	1,000
3	31794	NUT	1,000
4	31773	BOLT 5/1-18X0.5	1,000
5	31851	BOLT	1,000
6	31766	BOLT	1,000
7	33007	NUT 5/16-18	1,000
8	33013	NUT	1,000
9	31749	CLAMP HOSE	1,000
10	31748	CLAMP HOSE	1,000
11	33065	5/16 ID HOSE	1,000
12	33066	INLET TUBE LINER	1,000
13	33067	RADIATOR	1,000
14	33071	RADIATOR MOUNT	1,000
15	33072	BRACKET	1,000
16	33076	BELT SHIELD	1,000
17	33081	GRID LOW.LEFT	1,000
18	33082	GRID LOW.RGHT	1,000
19	33087	AIR CLEANER BRACKET	1,000
20	33088	EXHAUST FLANGE STUD	1,000
21	33089	BAFFLE SEAL UPPER	1,000
22	33090	BAFFLE SEAL LOWER	1,000
23	33091	FOAM SEAL	1,000
24	33105	FAN SHIELD WELDMENT	1,000
25	33225	SILENTBLOC	1,000
26	31741	AIR INLET TUBE	1,000
27	31742	RADIATOR HOSE, TOP	1,000
28	31743	RADIATOR HOSE	1,000
29	31744	SUBTANK, RESERVOIR	1,000
30	31745	SUBTANK BRACKET	1,000
31	31746	CLAMP, SUBTANK	1,000
32	31740	RADIATOR CAP	1,000
33	31739	AIR FILTER ASSY.	1,000
34	31967	ENGINE AIR FILTER	1,000
35	31747	INLET HOSE	1,000
36	33250	STEEL DEFLECTOR	1,000


A180/30



04/2010

Number	Part Number	Name	Quantity
1	31789	BOLT M8 X1.25X25	1,000
2	31824	BOLT	1,000
3	31821	BOLT 3/8-16X1,25	1,000
4	31817	BOLT	1,000
5	31822	BOLT	1,000
6	33007	NUT 5/16-18	1,000
7	31820	NUT 3/8-16 GR.2	1,000
8	31823	WASHER 1/2 LOCK	1,000
9	31825	WASHER 7/16"	1,000
10	31826	WASHER 3/8 LOCK	1,000
11	33026	WASHER 5/19 LOCK	1,000
12	33154	WASHER 3/8	1,000
13	31816	MOTOR MOUNT	1,000
14	31829	BRACKET	1,000
15	31818	BRACKET	1,000
16	33070	EXHAUST FLANGE STUD	1,000
17	33098	MUFFLER MOUNT	1,000
18	31819	BRACKET	1,000
19	31830	HEAT SHIELD	1,000
20	31827	MUFFLER ASS.	1,000
21	31831	GASKET	1,000


A180/28 8512 → . . .



12/2007

Number	Part Number	Name	Quantity
1	31983	CLIPS NUT	1,000
2	31824	BOLT	1,000
3	31821	BOLT 3/8-16X1,25	1,000
4	31817	BOLT	1,000
5	31822	BOLT	1,000
6	33000	BOLT 1/4-20X0.75	1,000
7	31820	NUT 3/8-16 GR.2	1,000
8	31823	WASHER 1/2 LOCK	1,000
9	31773	BOLT 5/1-18X0.5	1,000
10	31826	WASHER 3/8 LOCK	1,000
11	33013	NUT	1,000
12	33154	WASHER 3/8	1,000
13	31816	MOTOR MOUNT	1,000
14	33253	EXHAUST COLLAR	1,000
15	31818	BRACKET	1,000
16	33070	EXHAUST FLANGE STUD	1,000
17	33007	NUT 5/16-18	1,000
18	31819	BRACKET	1,000
19	33255	HEAT PROTECTION	1,000
20	33252	EXHAUST SILENCER	1,000
21	31831	GASKET	1,000
22	33254	EXHAUST JOINING	1,000


A180/29 8501→8511



12/2007

Number	Part Number	Name	Quantity
1	33187	INSTR.BOARD STICKER	1,000
2	13064	STICKER COLER OPEN	1,000
3	13134	ENGINE COVER LABEL	1,000
4	13195	STICKER-ARROW RIGHT	1,000
5	13187	STICKER"ATTILA 180"	1,000
6	13086	STICKER ETESIA	1,000
7	13228	STICKER BY-PASS	1,000
8	13062	STICKER CUT-DECK	1,000
9	33183	STICKER	1,000
10	33184	STICKER	1,000
11	13085	STICKER ETESIA	1,000

A180/31



Number	Part Number	Name	Quantity
1	13134	ENGINE COVER LABEL	1,000
2	13129	BATTERY LABEL	1,000
3	13186	STICKER "WARNING"	1,000
4	33167	DIESEL STICKER	1,000
5	33178	DIESEL STICKER	1,000
7	13218	STICKER "LEVELING"	1,000
8	13193	STICKER-PARK BRAKE	1,000
9	13062	STICKER CUT-DECK	1,000
10	13086	STICKER ETESIA	1,000
11	13187	STICKER"ATTILA 180"	1,000
12	13194	STICKER"ARROW LEFT"	1,000
13	13064	STICKER COLER OPEN	1,000

