

PB-251

Serial Number

37009053-99999999


Last updated date

14/Nov/2020

TABLE OF CONTENTS

CYLINDER, CRANKCASE, PISTON	1
STARTER, MAGNETO	3
AIR CLEANER, CARBURETOR, MUFFLER	5
HANDLE.....	7
FUEL TANK	9
FAN CASE, BLOWER PIPE.....	11
CARBURETOR.....	13
REPAIR KIT	15

CYLINDER, CRANKCASE, PISTON




CYLINDER, CRANKCASE, PISTON

Key No.	LV (+)	Parts Number	Parts Description	Qty	Standard	Class
1		900106-05008	BOLT, H.S. 5* 8	2	5*8	
2		A160-000821	COVER,CYLINDER	1		C
3		A130-000780	CYLINDER	1		D
4		900162-05025	BOLT, H.S. 5*25	4	5*25 W,SW	
5		V100-000190	GASKET,CYL	1		B
6		P021-010260	PISTON KIT	1		
7	+	A101-000140	RING, PISTON	1	B1.2 T1.5	B
8	+	V606-000000	PIN,ENG 8	1	5*8*28	D
9	+	100015-04630	CIRCLIP, PISTON PIN	2		C
10	+	100014-11520	SPACER, PISTON PIN	2		C
11		A011-000371	CRANKSHAFT,ASM	1		D
12	+	V553-000060	BEARING,NEEDLE 8	1	HK0810FMV4	B
13		P021-008231	CRANKCASE KIT	1		
14	+	100212-42031	OILSEAL	2	ISCD 12*22*4.5	C
15	+	900162-05028	BOLT, H.S. 5*28	3	5*28 W,SW	
16	+	100242-42030	GASKET, CRANKCASE	1		B
17	+	94035-36201	BEARING BALL	1	6201X3JR2C3	
18	+	100215-03930	PIN, DOWEL	2		C

Class : Consumable class

A:Fast moving parts B:Semi-fast moving parts C:Slow moving parts D:Order only as needed

STARTER, MAGNETO



060791


STARTER, MAGNETO

Key No.	LV (+)	Parts Number	Parts Description	Qty	Standard	Class
1		V485-000820	LEAD	1	CW104-#187	C
2		152115-05530	BUSHING	1		C
3		A425-000000	SPARKPLUG	1	BPMR8Y	A
4		A426-000010	TERMINAL,SPARKPLUG	1		C
5		A429-000010	COVER,CAP	1		C
6		A427-000013	CAP,SPARK PLUG	1		C
7		156110-04920	BUSHING	1		C
8		X532-000720	LABEL,OPERATION	1	SPARKPLUG BPMR8Y	D
10		91113-04020	BOLT	2	CM-4*20 SW,W	
11		A411-000290	COIL, IGNITION	1	EMG-60 ID#C10146	C
12		A409-000210	ROTOR,MAGNETO	1		C
12V		A409-001280	ROTOR,MAGNETO	1		C
13		E101-000071	HUB,FAN	1	M8*1.25	C
14		P021-013780	SPACER	1		
15	+	V263-000070	NUT,5	1		C
16	+	900163-04016	BOLT HSH	4		
17		A052-000250	PULLEY,ASM STARTER	1		C
18	+	900700-00004	E-RING 4	2	CE-4	
19	+	V452-000280	SPRING,TORSION	2		B
20	+	A514-000070	PAWL	2		C
21		A051-001060	STARTER,RECOIL ASY	1		B
22	+	177236-44330	SCREW	1		
23	+	P022-008260	ROPE	1	3M/M	
24	+	177215-44430	DRUM, STARTER	1		
25	+	177220-42030	SPRING, REWIND	1		
26	+	V420-001440	CUSHION	1		B
27	+	177246-11120	CLIP, STARTER ROPE	1		
28	+	177228-27030	GRIP, STARTER	1		C
29	+	177227-42030	GUIDE, ROPE	1		C
30		900106-05014	BOLT, H.S. 5*14	3	5*14	
31		X502-000330	LABEL,ECHO	1	ECHO	D
32		X503-008160	LABEL,MODEL	1	PB-251	D
33V		100142-12330	KEY, WOODRUFF	1		C

Class : Consumable class

A:Fast moving parts B:Semi-fast moving parts C:Slow moving parts D:Order only as needed

AIR CLEANER, CARBURETOR, MUFFLER




AIR CLEANER, CARBURETOR, MUFFLER

Key No.	LV (+)	Parts Number	Parts Description	Qty	Standard	Class
1		V299-000250	KNOB,FASTENER	1		C
2		131911-03460	WASHER	1		C
3		A232-000340	LID,CLEANER	1	ID#1220	C
4		X506-000090	LABEL,CHOKE	1		D
5		A226-000470	ELEMENT, AIR FILTER	1		A
5		A226-000471	ELEMENT, AIR FILTER	1		A
6		900105-05060	BOLT, H.S. 5*60	2	5*60	
7		A244-000070	PLATE,PREVENT	1		C
8		P021-010980	CLEANER CASE ASY	1		
9		130016-42031	GASKET, INTAKE	1		A
10		A021-001591	CARBURETOR,DIAPHRAGM	1	RB-K90	B
13		V103-000400	GASKET,INTAKE	1		A
14		900162-05025	BOLT, H.S. 5*25	2	5*25 W,SW	
15		A200-000280	INSULATOR, INTAKE	1		C
16		V103-000390	GASKET,INTAKE	1		A
17		A160-000830	COVER,CYLINDER	1		C
18		C459-000010	COVER,THROTTLE	1		C
19		V104-000820	GASKET,EXHAUST	1	NP7002	A
20		A300-000810	MUFFLER, EXHAUST	1		C
21		A310-000070	SCREEN, ARRESTOR	1	22*28*3	B
22		900603-00005	WASHER 5	2	5.5*12*0.8	
23		V203-000190	BOLT,5	2	AN A2-70	C
24		V104-000940	GASKET,EXHAUST	1	T:0.5	A
25		A313-000840	GUIDE, EXHAUST	1	20.5*3	C
26		A313-000850	GUIDE, EXHAUST	1	ID#1190	C
27		91367-04010	SCREW	5	4*10/SW(SUS)	
28		P021-011200	COVER,MUFFLER KIT	1		
29		900106-05014	BOLT, H.S. 5*14	2	5*14	
32		A313-001070	GUIDE, EXHAUST	1		C

Class : Consumable class

A:Fast moving parts B:Semi-fast moving parts C:Slow moving parts D:Order only as needed

HANDLE




HANDLE

Key No.	LV (+)	Parts Number	Parts Description	Qty	Standard	Class
1		900238-05025	SCREW 5*25	1	5*25	
2		900602-00005	WASHER 5	1	5.3*10*1	
3		C453-000260	LEVER, THROTTLE	1		C
4		900603-00005	WASHER 5	1	5.5*12*0.8	
5		C411-000010	LID,HANDLE	1	PB-251	C
6		900562-50005	LOCKNUT 5	1	5	
7		C450-000241	CONTROL, THROTTLE	1		C
8		900253-05025	SCREW 5*25	1	5*25	
9		900253-05020	SCREW 5*20	3	5*20	
10		C454-000130	ROD, THROTTLE	1		C
11		V431-000000	CABLE,INNER	1		C
12		C400-000471	HANDLE, FRONT	1		C
13		V263-000070	NUT,5	1		C
14		X505-002310	LABEL,CAUTION	1	HOT CAUTION	D
15		A440-000770	SWITCH, ON OFF	1	CA104/187 L140	C
16		V486-000070	TERMINAL,LEAD	1	C2801P-1/4H	C
17		890157-06560	LABEL, SWITCH	1		D
18		V485-000830	LEAD	1	187 / LA105 L250	C

Class : Consumable class

A:Fast moving parts B:Semi-fast moving parts C:Slow moving parts D:Order only as needed

FUEL TANK




FUEL TANK

Key No.	LV (+)	Parts Number	Parts Description	Qty	Standard	Class
1		131004-55530	CAP ASSY, FUEL TANK	1		
2	+	131016-55830	GASKET, FUEL CAP	1		A
3	+	131051-56030	CLIP, FUEL CAP	1	100L	B
4		A356-000030	VALVE,CHECK	1		B
5		132013-09820	CLIP	2	6MM	C
6		V471-001220	PIPE	1	3*5*50 NBR	C
7		132115-01461	GROMMET	1		C
8		900603-00005	WASHER 5	2	5.5*12*0.8	
9		900253-05020	SCREW 5*20	2	5*20	
10		V471-001860	PIPE	1	3*5*175	C
11		132010-49730	PIPE 3*6*85	1	3*6*85 YL	C
12		132115-44330	GROMMET	1		C
13		131205-07320	STRAINER, FUEL	1		A
14		A350-000550	TANK, FUEL	1		C
15		V420-001430	CUSHION	1		B

Class : Consumable class

A:Fast moving parts B:Semi-fast moving parts C:Slow moving parts D:Order only as needed

FAN CASE, BLOWER PIPE




FAN CASE, BLOWER PIPE

Key No.	LV (+)	Parts Number	Parts Description	Qty	Standard	Class
1		E104-000080	GRID, BLOWER	1		C
2		900253-05020	SCREW 5*20	3	5*20	
3		X547-000520	LABEL,ECHO	1	PB-251	D
4		X505-002080	LABEL,CAUTION	1		D
5		900253-05020	SCREW 5*20	8	5*20	
6		E103-000461	CASE,FAN	1		C
7		900100-08014	BOLT 8*14	1	8*14	
8		100143-19830	WASHER	1	8.2*31*0.8	C
9		E100-000070	FAN,BLOWER	1		C
10		E103-000451	CASE,FAN	1		C
11		900162-04020	BOLT, H.S. 4*20	4	4*20 W,SW	
12		E162-000000	FIXTURE, BLOW PIPE	2		C
13		900253-05020	SCREW 5*20	2	5*20	
14		C410-000391	HANDLE, REAR	1		C
15		C410-000400	HANDLE, REAR	1		C
16		900253-05020	SCREW 5*20	2	5*20	
17		E165-000191	PIPE,BLOWER	1		B
18		E165-000210	PIPE,BLOWER	1		B
19	+	E178-000050	GUARD,PIPE	1		D
20	+	V583-000080	RING	1	CE-5	C
21		895410-06960	WRENCH, W/S-DRIVER	1		D

Class : Consumable class

A:Fast moving parts B:Semi-fast moving parts C:Slow moving parts D:Order only as needed

CARBURETOR



CARBURETOR

Key No.	LV (+)	Parts Number	Parts Description	Qty	Standard	Class
		A021-001591	CARBURETOR,DIAPHRAGM	1	RB-K90	B
1	+	125344-13931	SCREW	3		
2	+	P005-002090	POST	1		
3	+	P005-002000	COVER ASY, ROTOR	1		
4	+	P005-000100	SCREW,THROTTLEADJUST	1		
5	+	P005-000190	E-RING	1		
6	+	P005-001270	PLUG, H AJUST SCREW	1		
7	+	P005-000280	O-RING	1		
8	+	P005-000940	SPRING, METER. LEVER	1		
9	+	125323-08260	ARM, VALVE	1		
10	+	125338-13930	PIN, METERING ARM	1		
11	+	125337-08260	VALVE, INLET NEEDLE	1		
12	+	125339-42030	SCREW	1		
13	+	P005-000200	GASKET, METERING	1		A
14	+	P005-001780	DIAPHRAGM	1		
15	+	125342-52130	COVER, DIAPHRAGM	1		
16	+	125344-52130	SCREW	1		
17	+	P005-000010	STRAINER	1		
18	+	P005-001260	SCREW,MAINN MIXTURE	1		
20	+	P005-001250	RETAINER,PLUG BALL	1		
21	+	P005-000510	DIAPHRAGM, PUMP	1		A
22	+	P005-000520	GASKET, PUMP	1		A
23	+	P005-001890	BASE, ASY PRIMER	1		
24	+	P005-000270	SCREW	1		
25	+	125381-08660	PUMP, PRIMING	1		
26	+	P005-000250	RETAINER	1		
27	+	P005-001900	SCREW	4		
28	+	P005-001000	ROLLER, GUIDE	1		
19		P005-001270	PLUG, H AJUST SCREW	1		

Class : Consumable class

A:Fast moving parts B:Semi-fast moving parts C:Slow moving parts D:Order only as needed

REPAIR KIT

REPAIR KIT

Key No.	LV (+)	Parts Number	Parts Description	Qty	Standard	Class
		P005-001660	DIAPHRAGM/GASKET KIT	1		
7-13		P005-000200	GASKET, METERING	1		A
7-14		P005-001780	DIAPHRAGM	1		
7-21		P005-000510	DIAPHRAGM, PUMP	1		A
7-22		P005-000520	GASKET, PUMP	1		A
		P005-001670	REBUILD KIT	1		
7-28		P005-001000	ROLLER, GUIDE	1		
7-17		P005-000010	STRAINER	1		
7-8		P005-000940	SPRING, METER. LEVER	1		
7-9		125323-08260	ARM, VALVE	1		
7-10		125338-13930	PIN, METERING ARM	1		
7-11		125337-08260	VALVE, INLET NEEDLE	1		
7-13		P005-000200	GASKET, METERING	1		A
7-14		P005-001780	DIAPHRAGM	1		
7-21		P005-000510	DIAPHRAGM, PUMP	1		A
7-22		P005-000520	GASKET, PUMP	1		A
		P021-012350	GASKET KIT	1		
1-5		V100-000190	GASKET,CYL	1		B
1-16		100242-42030	GASKET, CRANKCASE	1		B
3-16		V103-000390	GASKET,INTAKE	1		A
3-13		V103-000400	GASKET,INTAKE	1		A
3-9		130016-42031	GASKET, INTAKE	1		A
3-19		V104-000820	GASKET,EXHAUST	1	NP7002	A
3-24		V104-000830	GASKET,EXHAUST	1		A

Class : Consumable class

A:Fast moving parts B:Semi-fast moving parts C:Slow moving parts D:Order only as needed

NUMERICAL PARTS INDEX

Part No	Part description	Page	Part No	Part description	Page	Part No	Part description	Page
100014-11520	SPACER, PISTON PIN	2	900162-04020	BOLT, H.S. 4*20	12	A426-000010	TERMINAL,SPARKPLUG	4
100015-04630	CIRCLIP, PISTON PIN	2	900162-05025	BOLT, H.S. 5*25	2	A427-000013	CAP,SPARK PLUG	4
100142-12330	KEY, WOODRUFF	4	900162-05025	BOLT, H.S. 5*25	6	A429-000010	COVER,CAP	4
100143-19830	WASHER	12	900162-05028	BOLT, H.S. 5*28	2	A440-000770	SWITCH, ON OFF	8
100212-42031	OILSEAL	2	900163-04016	BOLT HSH	4	A514-000070	PAWL	4
100215-03930	PIN, DOWEL	2	900238-05025	SCREW 5*25	8	C400-000471	HANDLE, FRONT	8
100242-42030	GASKET, CRANKCASE	2	900253-05020	SCREW 5*20	8	C410-000391	HANDLE, REAR	12
100242-42030	GASKET, CRANKCASE	16	900253-05020	SCREW 5*20	10	C410-000400	HANDLE, REAR	12
125323-08260	ARM, VALVE	14	900253-05020	SCREW 5*20	12	C411-000010	LID,HANDLE	8
125323-08260	ARM, VALVE	16	900253-05025	SCREW 5*25	8	C450-000241	CONTROL, THROTTLE	8
125337-08260	VALVE, INLET NEEDLE	14	900562-50005	LOCKNUT 5	8	C453-000260	LEVER, THROTTLE	8
125337-08260	VALVE, INLET NEEDLE	16	900602-00005	WASHER 5	8	C454-000130	ROD, THROTTLE	8
125338-13930	PIN, METERING ARM	14	900603-00005	WASHER 5	6	C459-000010	COVER,THROTTLE	6
125338-13930	PIN, METERING ARM	16	900603-00005	WASHER 5	8	E100-000070	FAN,BLOWER	12
125339-42030	SCREW	14	900603-00005	WASHER 5	10	E101-000071	HUB,FAN	4
125342-52130	COVER, DIAPHRAGM	14	900700-00004	E-RING 4	4	E103-000451	CASE,FAN	12
125344-13931	SCREW	14	91113-04020	BOLT	4	E103-000461	CASE,FAN	12
125344-52130	SCREW	14	91367-04010	SCREW	6	E104-000080	GRID, BLOWER	12
125381-08660	PUMP, PRIMING	14	94035-36201	BEARING BALL	2	E162-000000	FIXTURE, BLOW PIPE	12
130016-42031	GASKET, INTAKE	6	A011-000371	CRANKSHAFT,ASM	2	E165-000191	PIPE,BLOWER	12
130016-42031	GASKET, INTAKE	16	A021-001591	CARBURETOR, DIAPHRAGM	6	E165-000210	PIPE,BLOWER	12
131004-55530	CAP ASSY, FUEL TANK	10	A021-001591	CARBURETOR, DIAPHRAGM	14	E178-000050	GUARD,PIPE	12
131016-55830	GASKET, FUEL CAP	10	A051-001060	STARTER,RECOIL ASY	4	P005-000010	STRAINER	14
131051-56030	CLIP, FUEL CAP	10	A052-000250	PULLEY,ASM STARTER	4	P005-000010	STRAINER	16
131205-07320	STRAINER, FUEL	10	A101-000140	RING, PISTON	2	P005-000100	SCREW, THROTTLEADJUST	14
131911-03460	WASHER	6	A130-000780	CYLINDER	2	P005-000190	E-RING	14
132010-49730	PIPE 3*6*85	10	A160-000821	COVER,CYLINDER	2	P005-000200	GASKET, METERING	14
132013-09820	CLIP	10	A160-000830	COVER,CYLINDER	6	P005-000200	GASKET, METERING	16
132115-01461	GROMMET	10	A200-000280	INSULATOR, INTAKE	6	P005-000250	RETAINER	14
132115-44330	GROMMET	10	A226-000470	ELEMENT, AIR FILTER	6	P005-000270	SCREW	14
152115-05530	BUSHING	4	A226-000471	ELEMENT, AIR FILTER	6	P005-000280	O-RING	14
156110-04920	BUSHING	4	A232-000340	LID,CLEANER	6	P005-000510	DIAPHRAGM, PUMP	14
177215-44430	DRUM, STARTER	4	A244-000070	PLATE,PREVENT	6	P005-000510	DIAPHRAGM, PUMP	16
177220-42030	SPRING, REWIND	4	A300-000810	MUFFLER, EXHAUST	6	P005-000520	GASKET, PUMP	14
177227-42030	GUIDE, ROPE	4	A310-000070	SCREEN, ARRESTOR	6	P005-000520	GASKET, PUMP	16
177228-27030	GRIP, STARTER	4	A313-000840	GUIDE, EXHAUST	6	P005-000940	SPRING, METER. LEVER	14
177236-44330	SCREW	4	A313-000850	GUIDE, EXHAUST	6	P005-000940	SPRING, METER. LEVER	16
177246-11120	CLIP, STARTER ROPE	4	A313-001070	GUIDE, EXHAUST	6	P005-001000	ROLLER, GUIDE	14
890157-06560	LABEL, SWITCH	8	A350-000550	TANK, FUEL	10	P005-001000	ROLLER, GUIDE	16
895410-06960	WRENCH, W/S-DRIVER	12	A356-000030	VALVE,CHECK	10	P005-001250	RETAINER,PLUG BALL	14
900100-08014	BOLT 8*14	12	A409-000210	ROTOR,MAGNETO	4	P005-001260	SCREW,MAINN MIXTURE	14
900105-05060	BOLT, H.S. 5*60	6	A409-001280	ROTOR,MAGNETO	4	P005-001270	PLUG, H AJUST SCREW	14
900106-05008	BOLT, H.S. 5* 8	2	A411-000290	COIL, IGNITION	4	P005-001660	DIAPHRAGM/GASKET KIT	16
900106-05014	BOLT, H.S. 5*14	4	A425-000000	SPARKPLUG	4	P005-001670	REBUILD KIT	16
900106-05014	BOLT, H.S. 5*14	6						

NUMERICAL PARTS INDEX

Part No	Part description	Page	Part No	Part description	Page
P005-001780	DIAPHRAGM	14	X547-000520	LABEL,ECHO	12
P005-001780	DIAPHRAGM	16			
P005-001890	BASE, ASY PRIMER	14			
P005-001900	SCREW	14			
P005-002000	COVER ASY, ROTOR	14			
P005-002090	POST	14			
P021-008231	CRANKCASE KIT	2			
P021-010260	PISTON KIT	2			
P021-010980	CLEANER CASE ASY	6			
P021-011200	COVER,MUFFLER KIT	6			
P021-012350	GASKET KIT	16			
P021-013780	SPACER	4			
P022-008260	ROPE	4			
V100-000190	GASKET,CYL	2			
V100-000190	GASKET,CYL	16			
V103-000390	GASKET,INTAKE	6			
V103-000390	GASKET,INTAKE	16			
V103-000400	GASKET,INTAKE	6			
V103-000400	GASKET,INTAKE	16			
V104-000820	GASKET,EXHAUST	6			
V104-000820	GASKET,EXHAUST	16			
V104-000830	GASKET,EXHAUST	16			
V104-000940	GASKET,EXHAUST	6			
V203-000190	BOLT,5	6			
V263-000070	NUT,5	4			
V263-000070	NUT,5	8			
V299-000250	KNOB,FASTENER	6			
V420-001430	CUSHION	10			
V420-001440	CUSHION	4			
V431-000000	CABLE,INNER	8			
V452-000280	SPRING,TORSION	4			
V471-001220	PIPE	10			
V471-001860	PIPE	10			
V485-000820	LEAD	4			
V485-000830	LEAD	8			
V486-000070	TERMINAL,LEAD	8			
V553-000060	BEARING,NEEDLE 8	2			
V583-000080	RING	12			
V606-000000	PIN,ENG 8	2			
X502-000330	LABEL,ECHO	4			
X503-008160	LABEL,MODEL	4			
X505-002080	LABEL,CAUTION	12			
X505-002310	LABEL,CAUTION	8			
X506-000090	LABEL,CHOKE	6			
X532-000720	LABEL,OPERATION	4			