

STARK 25 Brushcutter



Documents

Engine

Starter assy and clutch

Transmission

Tank and air filter

Carburettor WYL-205B

Accessories

Illustrated part list (Head "Load & Go" D.130)








Illustration Engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	3960067AR	Screw				
2	1	4161570R	Short block				
3	1	4098683R	Washer				
4	1	61030182R	Plug				
5	4	3819006R	Washer				
6	4	3801015R	Screw				
7	1	61010001R	Cover				
8	2	3916005R	Washer				
9	1	61010005	Muffler cover				
10	2	3806028	Screw				
11	1	4095211R	Plate				
12	1	61010011	Gasket				
13	1	072700048R	Piston ring Ø34				
14	2	3801010R	Screw				
15	2	4160025R	Ring				
16	1	4161030CR	Piston assy Ø34				
17	1	3055101R	Spark plug				
18	1	4098232R	Key				
19	1	3064005AR	Washer				
20	1	3024010R	Snap ring				
21	1	3037026R	Thrust bearing				
22	1	4161599AR	Connecting rod				
23	1	61030174R	Crankshaft				
24	1	61010012R	Muffler				
25	1	3034003R	Bearing				
26	2	3025019R	Ring				
27	1	3035023R	Bearing				
28	1	4160124R	Washer				
29	1	3050030R	Seal ring				




Illustration Starter assy and clutch

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	4160125R	Starter rope				
2	1	61030179R	Flywheel				
3	1	4191020AR	Starter handle				
4	1	3024018R	Ring				
5	1	4161150R	Ring				
6	1	4161148AR	Pulley				
7	1	004000132R	Spring				
8	1	4162358	Cable				
9	1	4161160AR	Starter assy				
10	1	4160072R	Spacer				
11	4	3801011R	Screw				
12	1	61010027R	Starter case				
13	4	3916005R	Washer				
14	4	3819006R	Washer				
15	4	3801009R	Screw				
16	2	4161151	Pin				
17	2	4138441R	Pawl				
18	2	4161186A	Spring				
19	2	3801101R	Screw				
20	1	2501009R	Ignition coil				
21	1	4098064R	Spark plug cap				
22	1	61030177R	Clutch				
23	2	3916004R	Washer				
24	2	3819005R	Washer				
25	2	3806035R	Screw				
26	1	61030190R	Spring				
27	1	4160146AR	Deflector				
28	1	61030189R	Clutch driver				
29	2	3918007R	Washer				
30	1	61030191R	Bushing				
31	1	61010021	Adaptor				
32	1	61010020R	Adaptor				
33	1	4161364R	Bushing				
34	1	4161428AR	Sleeve				
35	1	3035023R	Bearing				
36	1	3024012R	Snap ring				
37	1	4161343R	Clutch drum				
38	1	3025019R	Ring				
39	1	61032029AR	Clutch cover				
40	2	3801016R	Screw				
41	4	4175074R	Screw				

Illustration Starter assy and clutch

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
42	2	3914003R	Nut				




Illustration Transmission

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	3819006R	Washer				
2	1	3801015R	Screw				
3	1	61170132R	Grommet				
4	1	4160262R	Knob				
5	1	4179141R	Washer				
6	1	4160005R	Flange				
7	1	074000183AR	Clamp	06/2011			BT3-106-04/11
8	1	3960021	Screw				
9	1	4100456R	Guard				
10	1	4160011R	Tube Ø26	SN 9026439043	SN 9022521605		BT3-120-07/13,
11	3	3914003R	Nut				
12	1	2317021R	Switch				
13	1	4138358R	Button				
14	1	4138360R	Spring				
15	1	4174246AR	Lever				
16	1	4174245CR	Throttle lever				
17	1	4138361R	Spring				
18	1	3801008R	Screw				
19	1	4100098BR	Spring				
20	2	3960029	Screw				
21	2	3801016R	Screw				
22	1	4095032A	Knob				
23	1	4174187ER	Handlebar				
24	1	61040131R	Handle				
25	1	4161439AR	Throttle cable				
26	1	4161440AR	Cable				
27	1	4161477AR	Handlebar				
28	1	62030042R	Drive shaft				
29	2	072700082R	AV-mount				
30	1	3025021R	Ring				
31	1	4138359R	Button				
32	1	4160012AR	Kegelradantrieb Ø26				
33	1	3024010R	Snap ring				
34	1	3035005R	Bearing				
35	1	4161619AR	Band				
36	1	3025018R	Ring				
37	1	4160004BR	Flange				
38	1	3035012R	Bearing				
39	1	4138311A	Ring				
40	1	3025009	Ring				
41	1	4160139	Bevel gear set				

Illustration Transmission

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
42	1	4138428	Cap				
43	1	4160338R	Gear case				
44	1	4162177AR	Guard				
45	1	3806069R	Screw				
46	1	094000006R	Bearing				
47	1	4162178	Spring				
48	1	3916008R	Washer				
49	2	3801013R	Screw				
50	1	072700264CR	Clamp	06/2011			BT3-106-04/11
51	1	4160011R	Tube Ø26	SN 9022521606	SN 9026439042		BT3-120-07/13





Illustration Tank and air filter

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61162017A	Air filter kit				
2	1	61010004R	Stand				
3	3	3918010R	Washer				
4	3	3960115R	Screw				
5	1	61160014AR	Air filter				
6	1	4161438R	Gasket				
7	2	3801051R	Screw				
8	1	4162256BR	Insulator				
9	1	61030112BR	Gasket				
10	2	3801012R	Screw				
11	2	3833073R	Washer				
12	1	4162297R	Tube				
13	1	4098377R	Band				
14	1	4162316R	Tube				
15	1	3059002	Band				
16	1	4162270AR	Fittings				
17	1	4162268R	Bushing				
18	1	4098658AR	Breather valve				
19	1	4151258R	Complete cap				
20	1	4100308AR	Gasket				
21	1	3073019AR	Tube				
22	3	3801010R	Screw				
23	1	094600450R	Fuel filter				
24	1	61032026AR	Complete tank				
25	1	61010002R	Support				
26	3	3918005R	Washer				
27	3	3819006R	Washer				
28	1	2318394R	Carburetor		SN 9022521829		BT3-120-07/13
29	1	3049040R	O-ring		SN 9022521829		BT3-120-07/13
30	1	61150025R	Bracket		SN 9022521829		BT3-120-07/13
31	1	61010030B	Carburetor kit		SN 9022521829		BT3-120-07/13
32	1	2318394R	Carburetor	SN 9022521830			BT3-120-07/13
33	1	2318395R	Gasket set	SN 9022521830			BT3-120-07/13




Illustration Carburettor WYL-205B

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2318583	Screw				
2	2	2318954	Screw				
3	1	2318568	Spring				
4	1	2318674	Repair kit				
5	1	2318577	Adjuster nut				
6	1	2318189	Ring				
7	1	2318958	Valve				
8	1	2318567	Pump body				
9	1	2318569	Screw				
10	1	003300201	Spindle				
11	1	2318570	Primer body				
12	1	2318592	Valve				
13	4	2318585	Screw				
14	1	2318572	Primer pump				
15	1	2318571	Cover				









Illustration Accessories

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1		-	Not available for this product			Sostituita da testina completa codice 63019022 (inserto maschio), 63019020 (inserto	
2	2	3960040R	Screw				
3	1	61240161R	Plate				
4	4	3801011R	Screw			complet head p/n 63019022 (male insert) 63019020	
5	1	61330252	Skirt w/blade				
6	1	4174275R	Blade				
7	1	61030198	Disc guard				
8	1	4199005AR	Bushing				BT2-020-06/07
9	1	63030009R	Insert (male)				BT2-020-06/07
10	1	4199004R	Spring				BT2-020-06/07
11	1	4199041R	Nylon spool Ø2,4				
12	1	4199035BR	Cover				
13	1	4095673BR	3-tooth blade				
14	1	61052031R	Tool kit				
15	1	4160463AR	Single harness				
16	1	61032046	Labels kit				
17	4	3819006R	Washer				
18	4	3914003R	Nut				
19		-	Not available for this product			Sostituita da testina completa codice 63019022 (inserto maschio), 63019020 (inserto	
20	1	61110076R	Insert (female)				
21	1	4199026A	Cover				
22	1	4199046	Cover			complet head p/n 63019022 (male insert) 63019020	
23	1	61459101	Head Tap&Go			Inserto maschio; Male insert	BT2-020-06/07
23	1	61459101	Head Tap&Go			Inserto femmina; Female	
24	1	4199052	Nylon spool				BT2-020-06/07




Illustration Illustrated part list (Head "Load & Go" D.130)

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	63129007	Load & Go nylon head			Easy&LongLife	
1	1	63129014	Head Load&Go			ExtraLife	
2	1	63120041R	Insert				
3	1	63120040R	Nut				
4	1	63120031R	Kit spring				
5	1	63120020AR	Nylon spool				
6	1	63120007AR	Knob			Easy&LongLife	
6	1	63120030AR	Knob			ExtraLife	
7	2	63120001R	Bushing				
8	1	63120005R	Cover				